



PLAY MIX – Dash & Dot

Get Started with Dash & Dot

Intro: The Difference Between Dash & Dot

Dash is the large robot with wheels. Dash can move, rotate his head, sing or make sounds, light up, and respond to voices.

Dot is the small robot. Dot can sing or make sounds, light up, and respond to voices. Dot doesn't move (unless you toss it) and is used primarily for programming and playing games.

Getting Started

Prep:

Charge Dash and Dot with the provided orange cable before using. A typical charging time using most tablet USB wall chargers is 60-90 minutes per robot. Only one charging cable is provided.

Steps:

1. Download the Wonder app.
2. Turn on Dash and Dot robots. (You can work with both at the same time, but for practice, we recommend starting with Dash.)
3. Connect your robot via Bluetooth. Put it on the floor, navigate to Bluetooth on your smart phone or tablet, and sync.
4. Open the Wonder app and follow the instructions to set up your robot.
5. Play with the Wonder app until you get the idea, then try out other apps listed on the "Dash & Dot Apps and Sites" sheet.

Mix it Up:

Test out the various accessories and attachments included in the Play Mix to see what they do!

Visit here for helpful instructions and diagrams to get started:

https://www.makewonder.com/play/setup/building_brick_extensions

Attachment list

Building Brick connectors pack (6 connectors)

1 tail

2 bunny ears

1 smartphone mount

1 pusher bar

1 tow hook

Dash xylophone + mallet